HP 3000 SERIES II COMPUTER SYSTEM MANUAL OF STAND-ALONE DIAGNOSTICS

STAND-ALONE HP 30103A (2660A) FIXED HEAD DISC DIAGNOSTIC

Diagnostic No. D428A

2/76



30103-90015 Printed in U.S.A.

NOTICE

The information contained in this document is subject to change without notice.

HEWLETT-PACKARD MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATER-IAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material.

Hewlett-Packard assumes no responsibility for the use or reliability of its software on equipment that is not furnished by Hewlett-Packard.

This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced or translated to another program language without the prior written consent of Hewlett-Packard Company.

Copyright @ 1976 by HEWLETT-PACKARD COMPANY

TABLE OF CONTENTS

| Section | Ι. | | INTR | DDUC. | TIO | N. | • | • | * | . • | • | • | • | • | • | .* | • | ٠ | • | • | 2 |
|---------|-----|-------|------|-------|-----|-----|----|-----|----|-----|-----|----|----|-----|---|----|---|---|---|---|----|
| Section | II | • | MINI | OPE | RAT | ING | I | NST | RU | CT | 10 | N | • | • | • | •. | ٠ | ٠ | • | ٠ | 3 |
| Section | II | I. | REQU | IREM | ENT | s. | ٠ | • | ٠ | • | ٠ | • | • | • | • | • | • | • | ٠ | • | 4 |
| Section | ĮV | • | DETA | ILED | OP | ERA | TI | NG | IN | ST | 'RU | CT | 10 | N S | • | • | • | • | • | ÷ | 5 |
| Tes | t S | ectio | ons. | | • | | ٠ | • | • | • | • | • | • | • | ٠ | • | • | • | ٠ | • | 9 |
| Sta | tus | and | Erro | r De | tec | tio | n | • | ٠ | • | • | • | • | • | • | • | • | ٠ | • | • | 15 |
| Mes | sag | e Ana | lysi | 5. | • | | • | | • | | • | • | | | • | • | • | | | • | 17 |

The fixed head disc diagnostic is a stand-alone program written in SPL/3000 and prepared with SDUP as a cold loadable diagnostic. The diagnostic will verify the correct operation of the fixed head disc subsystem.

II. MINI OPERATING INSTRUCTION

DØØ6 END OF PASS ØØ1

for 4 MBYTE)

III. REQUIREMENTS

The fixed head disc diagnostic will run on a minimum HP 3000 Series II Computer System with a fixed head disc.

.۵.

IV. DETAILED OPERATING INSTRUCTIONS

- 1. Mount the cold loadable I/O standalone tape containing the fixed head disc diagnostic on DRT 6 unit \emptyset .
- 2. Set the switch register to %3006, then simultaneously depress the ENABLE and LOAD switches.

A short length of tape should load and the CPU will halt.

- 3. Set the switch register to the diagnostic number of the fixed head disc diagnostic.
- 4. Press RUN. The tape should load and rewind.
- 5. Press RETURN on the console, the message: DØØØ FIXED HEAD DISC DIAGNOSTIC (HP D428A.XX) PØØ8 ENTER DEVICE NUMBER

-5-

- 6. Enter the decimal device number of the fixed head disc controller. Press RETURN.
- 7. The message: P009 ENTER FIRST AVAILABLE TRACK

Will be printed.

8. Enter the first track to be tested, usually \emptyset . Press RETURN

9. The message:

PØ1Ø ENTER LAST AVAILABLE TRACK

Will be printed.

10. Enter the last track to be tested.

255 for 2 MBYTE disc

511 for 4 MBYTE disc

Press RETURN.

11. The message:

D14 SET SWITCH REGISTER

Will be printed. The CPU will halt. CIR=%030364

12. Set the switch register bits \emptyset and 1. Press RUN.

13. The message:

D15 SELECT SECTIONS

Will be printed.

14. Set the B switch register bits 1 through 6. Press RUN.

TABLE 1. SWITCH REGISTER AND SECTION SELECT OPTIONS

| × . | | SWITCH REGI | ISTER |
|-----|------------|-------------|----------------------------------|
| | BIT | | FUNCTION |
| | Ø | | Select external switch register |
| | 1 | | Select section select register |
| | 10 | | Suppress error messages |
| | 11 | ~ | Loop on last step |
| | 12 | | Halt on error |
| | 13 | | Halt at end of step |
| | 14 | | Halt at end of section |
| \ | 15 | | Halt at end of program |
| | - - | SECTION ELE | CT REGISTER |
| | BIT | | FUNCTION |
| | 1 | | Select section 1 |
| | 2 | | Select section 2 |
| | 3 | | Select section 3 |
| | 4 | | Select section 4 |
| | 5 | | Select section 5 |
| | 6 | | Select section 6 |
| | 7 | | Select section 7 |
| | HALT CODES | SEGMENT | MEANING |
| ľ | %0 30 36 4 | 3 | Halt for switch register |
| | %030365 | 3 | Halt for section select |
| | %030366 | 3 | Halt for restore switch register |
| | %030372 | 3 | Halt on error |
| | %0 30 37 3 | 3 | Halt at end of step |
| | %030374 | 3 | Halt at end of section |
| | %030375 | 3 | Halt at end of diagnostic |

15. The message:

D16 RESTORE SWITCH REGISTER

Will be printed.

16. Set the switch register bits \emptyset and 15. Press RUN.

17. The message:

E1Ø9

EØØI NSW 1ØØØØØØØØØØØØ

Will be printed designating no tracks are protected. The diagnostic runs approximately 40 minutes for 511 tracks at the end the message.

DØØ6 END OF PASS XXX

Will be printed and the diagnostic halts.

CIR = %030375.

Press RUN to continue.

TEST SECTIONS

The diagnostic is divided into seven sections. Sections 1 through 7 each consist of a logical set of tests or functions. Each test or function is a uniquely numbered step.

A control section makes up the outer block of the diagnostic and controls its operation. It calls numbered sections as procedures selectively and in sequence according to switch settings selected during configuration.

Summary of Test Sections

There are seven test sections:

<u>Section 1</u> verifies the proper execution of the instructions TIO and CIO to disc. Status bits, tracking and addressing conditions are tested.

<u>Section 2</u> checks read/write functions with Cyclic Redundancy Check (CRC) disabled.

<u>Section 3</u> checks CRC operation and read/write functions with CRC enabled.

Section 4 verifies read operation following write operation.

<u>Section 5</u> performs surface analysis and verifies proper head selection.

<u>Section 6</u> performs random read and write operations of variable numbers of sectors with changing data patterns.

<u>Section 7</u> tests the power-fail protection capability of the Fixed Head Disc.

Summary of Test Section Steps

Table 1 summarizes the steps performed in sections 1 to 7.

Table 1. Test Steps

| Step Number | Function | | | | |
|-------------|---|--|--|--|--|
| | Section 1 | | | | |
| 101 | Test response to Test 1/0 | | | | |
| 102 | Test response to Control 1/0 | | | | |
| 103 | Test status bit 0; Start 1/0 allowed | | | | |
| 104 | Test status bit 1; RIO/WIO allowed | | | | |
| 105 | Test status bit 2; interrupt request | | | | |
| 106 | Test status bit 3; disc not ready (special man- ual operator procedures required; will only run if switch 7 is ON). | | | | |

| Step Number | Function |
|-------------|---|
| | Section 1 (Continued) |
| 107 | Test status bit 7; track address out of bounds |
| 108 | Test status bit 5; abort |
| 109 | Test status bit 8; attempt to write on protected tract (one error will occur if there are NO pro-tected tracks) |
| 110 | Test status bit 9; Arc address out of bounds (Arc 63) |
| 111 | Test that Arc number increments, then gets reset to 0 after highest Arc address, 31 |
| | Section 2 |
| 204 | Write first available track sector 0 with worst case pattern* |
| 205 | Write first available track sector 7 with worst case pattern for two sectors |
| 206 | Read first available track sector 0 back again an verify contents |
| 208 | Read first available track starting at sectors 7 for two sectors and verify contents |
| 210 | At first available track sector 29 write four sectors of second pattern* causing track to chang |
| 213 | Write first available track sector 0 with second pattern |
| 214 | At sector 29 read 4 sectors and compare data |
| 216 | Read back and verify sector O |
| 218 | Write 129 words on sector 0 of first available track, data chain, write another 129 words |
| 219 | Read 129 words on sector 0 of first available tra data chain, read another 129 words |
| 220 | Write 150 words on first available track sector O |
| 221 | Read 150 words on first available track sector 0 |
| | terns used are: 0666666, 1333333, 111111, 155555, |

| Step Number | Function |
|-----------------------|--|
| 944 - ¹ 44 | Section 2 (Continued) |
| 222 | Write 10 words, data chain, write another 10 words from first available track |
| 223 | Read 258 words, check fill from first available track sector 0 |
| 224 | Write 1 word, data chain, write another word from first available track sector 0 |
| 225 | Read back and check for fill 258 words from sector 0 |
| 226 | From first available track sector 0 write 2 words, data chain, write 2 more words |
| 227 | Read back 258 words and check for fill |
| 228 | Write 127 words, data chain, write 127 more words from first available track sector O |
| 229 | Read back 258 words and check for fill |
| 230 | Write 128 words, data chain, write another 128 words from first available track sector O |
| 231 | Read back 258 words and check for fill |
| 234 | Write 130 words on first available track sector O |
| 2 35 | Read back 258 words and check for fill |
| | Section 3 |
| 301 | At sector 0 of first available track write worst case pattern with CRC (cyçlic redundancy check) enabled |
| 302 | Read back sector 0 and check for CRC error |
| 30 3 | Read sector 7 with CRC enabled (sector 7 was written with CRC disabled in step 204) and verify status bit 4, CRC check failed (step 204 called by this step |
| 304 | Write first available track sector 5 for 5 sectors (CRC enabled) with 5 worst case data patterns |
| 305 | Read sector 5 for 5 sectors (CRC disabled) and verify that expected CRC was generated during step 304 |
| 306 | At sector 29 write 4 sectors of first available track with CRC enabled using pattern 3 |
| 307 | At sector 29 read 4 sectors and verify contents written in step 306 |

-12-

| <u>`</u> | Step Number | Function |
|----------|-------------|--|
| | | Section 4 |
| | 401 | Write on sector 1 and read sector 3 on first avail- able track verifying that this occurred on the same disc revolution (repear this action 1024 times) |
| | 407 | Test SIN CPU instruction to insure that it causes disc logic to interrupt |
| | | Section 5 |
| <u> </u> | 501 | Write all surfaces except write protected tracks with worst case data patterns; read back and verify contents; Repeat for each of the 5 worst case data patterns; the first word of each sector will be the sector number and the second word of each sector will be the track address; the device is alternately written forward and backward. If a verify error occurs, retry procedure will be used for sectors containing error, The sectors in error are reread and verified 100 times. Message E005 is printed. |
| | | Section 6 |
| | 502 | Format entrie disc from first available track with 4 worst case data patterns; first word of each sector will contain sector number; second word of each sector will contain track address; remainder of each sector will contain a worst case data pattern according to the following scheme |
| | | If remainder of $S/4 = 0$, then pattern 1 |
| | | If remainder of $S/4 = 1$, then pattern 2 If remainder of $S/4 = 2$, then pattern 3 |
| | | where S is the Sector number |
| | 503 | Randomly write and read a variable number of sectors (1 to 4), each write to be followed by a read and each read to be followed by a compare of expected data (repeat action 1024 times). If there is a compare error, retry procedure will be used. The sectors in error are reread and verified 100 times. Message E005 is printed. |

| Step Number | Function |
|-------------|--|
| 610 | Section 6 (Contined) This step prints "END OF PASS n" and rotates data patterns, i.e., pattern 5 becomes pattern 1, pattern 1 becomes pattern 2, etc. This is always the last step executed in the diagnostic, whatever sections are executed. |
| 602 | Step 602 writes and reads entire disc with random data from first available track to last available track. As much of the disc as possible is written and read in 10 track increments, the remainder of the disc is written and read in 1 track increments. |
| 604 | Step 604 writes track addresses on each track from first available track to last available track then reads and compares the addresses. The disc is written and read forward then backwards. |
| | Section 7 |
| 701 | Write 31 sectors on first available track and jump back to write continuously; the user is instructed to turn power off, then on; the program hangs in a TIO loop waiting for DISC NOT READY; when this |
| | occurs, it waits for Dist READY; when Dist READY occurs, the entire dist is read and checked for CRC errors. At most, one CRC error should be de- tected (the user may have to repeat test a few times to get CRC error, since power off/on dequence might have been performed too early or late for dist write activity). CRC error track is corrected. |
| 702 | Read 31 sectors on the first available track and jump back to read continuously; user is instructed to turn power off and then on again; the program hangs in a TIO loop waiting for DISC NOT READY; when this occurs, it waits for DISC READY; when that occurs, the entire disc is read and checked for CRC errors. No CRC errors should be detected. |

STATUS AND ERROR DETECTION

The diagnostic program monitors status of the fixed head disc. Wherever status is not as expected, the user is notified via a diagnostic message.

Status

The Status Register contains information that can be requested by the CPU. Under normal conditions, the Normal Status Word (NSW) is available. Two other status words, Error Status Words (ESW1 and ESW2), are available under error conditions. Status word formats are shown in Figure 1.

| | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | |
|------|---|-----------|----|------|---|---------|---------------|----------|------|-----------|----|------|------------|------|-----|----|---|
| NSW | | | St | atus | R | egi | stei | ŕ | | ~. · · | | Ar | c A | ddre | ess | 1 | - |
| ESW1 | | | St | atus | R | egi | s te i | <u>^</u> | | | | Ar | C A | ddre | ess | 2 | • |
| ESW2 | | <u>\$</u> | | | | | ومرود التحديد | | Trac | <u>ck</u> | Ad | dres | <u>s s</u> | | | | _ |

Figure 1. Status Words

Status Register, bits O through 9, hold the disc status.

Meaning

- SIO allowed. This bit will be 1 if the FHDC is in a state where it will accept an SIO-command. It will be 0 if (1) An 1/0 program is currently running on the controller, (2) the disc is not up to speed or not ready for other reasons. (3) an interrupt (not masked off) is pending.
- 1 RIO/WIO allowed. Always O.
- 2 Interrupt Request. This bit will be 1 also if the interrupt is masked off.
- 3 Disc not ready.

Status Register, bits 0 through 9, hold the disc status. (Continued)

Meaning

| 4 | CRC check failed. Note: This check takes place at the beginning of the following sector. This means that the Arc Address will be pointing to the arc after, and also the Track Address will have been incremented if the error occurred in the last sector of a track and transfer would have continued on the next track. |
|---|---|
| 5 | Abort. Will be set if an error occurs. |
| 6 | Transfer error. This bit will be set if an irregularity in the timing causes loss of data. It will also be set by External Transfer Error (parity error on the data bus) or CRC error. |
| 7 | Track address outside bounds. The validity of the track address will be tested after the Write or Read order has been issued. |
| 8 | Write reject. Will be set if an attempt is made to write on a protected track. |
| 9 | Arc address outside bounds. If no match takes place be- tween the Arc Counter and the Arc Address register after one full revolution, then the arc address (loaded by the Control order) is outside bounds. The FHDC will set this error bit if no match has been found after two Track Origin pulses (index marks on the disc). |

Arc Address 1 holds are currently under the heads (rotational position of the disc). Arc Address 2 holds arc where error occurred. S holds the first four bits of the Status Register (see above). Track Address holds track where error occurred.

Cyclic Redundancy Check

Bit

The fixed head disc contains a Cyclic Redundancy Check (CRC) generator. During writing, it processes the data for every sector and generates a CRC word. This word is then written in the sector. During read, the CRC generator processes the data read from disc and verifies CRC value. If CRC value is incorrect, disc enters error state.

MESSAGE ANALYSIS

Messages are sent to the operator via the control console. All messages have the following format: a letter prefix; a three digit decimal number, and text, if any. The letter prefix indicates the class of the message. There are four message classes.

| Message Class | Meaning |
|---------------|--|
| D | Data information which requires no operator input. |
| P | Diagnostic program has paused, waiting for operator action. |
| E | Error message which indicates disc or disc controller failure. |
| Q | Request for operator to perform input via control console. |
| | |

For D and P class messages, the three digit number indicates message number as described in Table 4. Two possibilities exist for E class messages. If the first digit is non-zero, the three digit number indicates step number where the test failure occurred. If the first digit is zero, interpret three digit number as indicated in Table 4. Error message example:

| Message | Meaning |
|-------------------------|--|
| E101 | Test failure at step 101 |
| E006 NO RESPONSE TO TIO | Disc does not respond properly to Test I/O instruction |

| ***** | Message | Description |
|-----------|---|--|
| D000 | FIXED HEAD DISC DIAG- NOSTIC (HP D428A.XX) | Test preamble. |
| D006 | END OF PASSn | Printed after each pass through diagnostic; n incremented after each printing. |

Table 4. Diagnostic Messages

-17-

Table 4. Diagnostic Messages (Continued)

| Message | | Description |
|--------------|---|--|
| D007 | HALT AT STEPn | Step HALT option printout (SW.15);n is step number. |
| D008 | HALT AT SECTIONn | Section HALT option printout (SW.9);n is section number. |
| E001 | NSW XXXXXXXXXXXXX EXPECTED NSW XXXXXXXXXXXXXXX | Normal status word (NSW) is not as expected; X's hold binary word con- tents. EXPECTED status only printed when a specific status expected. |
| E002 | ESW1 XXXXXXXXXXXXX EXPECTED ESW1 XXXXXXXXXXXXXX | Error status word one (ESW1) not as expected; X's hold binary word con- tents. EXPECTED status only printed when a specific status expected. |
| E00 3 | ESW2 XXXXXXXXXXXXX EXPECTED ESW2 XXXXXXXXXXXXXX | Error status word two (ESW2) not as expected; X's hold binary word con- tents. EXPECTED status only printed when a specific status expected. |
| E004 | DATA WORDn IS YYY SHOULD BE ZZZZZZZ | The nth data word returned on a read operation holds value YYYYYY instead of proper value ZZZZZZZZ |
| E005 | 100 RETRIES n UNSUCCESSFUL m SUCCESSFUL | Retry report used in steps 501 and 605 when an error is detected. n is the number of unsuccessful read and/or compare combinations; m is the number of successful read/compares. |
| E00 6 | NO RESPONSE TO TIO | Disc did not respond to Test 1/0 instruction. |
| E007 | NO RESPONSE TO CIO | Disc did not respond to Command 1/0 instruction. |
| E008 | CRC XXXXXXXXXXXXXX EXPECTED CRC XXXXXXXXXXXXXXX | The Cyclic redundancy check (CRC) is not as expected; X's hold binary value. |
| E009 | NO RESPONSE TO SIO | Disc did not respond to Start 1/0 instruction. |
| E010 | ARC IS XXXXXXXXXX Expected Arc XXXXXXXXXXXXXXX | Arc value is not as expected; X's hold binary arc value. |
| E011 | NO INTERRUPT FROM SIN CPU INSTRUC- TION | No interrupt received as expected after SIN instruction executed in CPU. |

Table 4. Diagnostic Messages (Continued)

| Message | | Description |
|---------|--|---|
| E012 | NO INTERRUPT FROM SIO | Start 1/0 instruction did not cause interrupt. |
| E013 | NSW IS XXXXXXXXXXX SHOULD BE XXXXXXXXXXX TRACK = XXX ARC = XXX | Status error in section 6. |
| E101 | | Typical step number error printout. |
| P007 | TURN POWER OFF THEN ON | Used in section 7 to test power failure. Turn disc power off and then immediately on again. |
| P008 | ENTER DEVICE NUMBER | Enter 3 decimal digit DRT number, |
| P009 | ENTER FIRST AVAILABLE TRACK | Enter up to 4 digits for decimal number of first available track. |
| P010 | ENTER LAST AVAILABLE TRACK | Enter up to 4 digits for decimal number of last available track, |
| P011 | TURN POWER OFF, PRESS RUN, TURN POWER ON | Used in step 106 to test status bit 3. |

-19-

